


# QUICK SET-UP GUIDE


## 2

Mounting Position




## 1

Location



## 4

Temperature




- Press and hold for 2 seconds to power the control on / off.
- Press to increase required pool temperature.
- Press to decrease required pool temperature.
- Press and release to activate / deactivate 'Priority of Heating'

## 3

Connection

The heater must be installed in accordance with the country / regional requirements and regulations.  
The heater must be installed by a qualified electrician who will provide a certificate of conformity upon completion of the work.



The actual pool temperature is displayed in the red upper display. The lower green display 'required temperature' can be selected by the user. This is the temperature you would like your pool water to be maintained at.